

# Hercules 2 - Quick reference guide


## Safety instructions

- This document is not a replacement for the user's guide. Please refer to the user's guide for more details.  
**DO NOT LEAVE ANY PROBLEM UNRESOLVED. NEVER SACRIFICE SAFETY FOR ANY REASON**

### 1. Installation

- Tilting of the sensor recommended approximately 30°- 45°
- The unit is ready for operation once all wiring is completed and the power is applied, the LED's stopped flashing, indicating that the learning cycle has been completed.

### 2. Electrical Connections / Installation:



### 3. Manual set-up, please refer to the user's guide

### 4. Remote set-up [with RC Duo remote control]

- Point RC Duo (remote) to the sensor and press the "G" key to establish a link.
  - If the connection has been established successfully, "G" and one of the keys "1" - "7" lights up (address of the sensor).
  - If "G" flashes, connection could not be established.
- During the changing of settings:
  - Flashing keys** on the RC Duo indicate that the data has not been fully transmitted or accepted.
  - Steady siid illuminated keys** on the remote indicate that settings have been stored.

### 5. Remarks:

- The sensor will automatically go into a safe mode 30 min after the last change of settings, inhibiting anyone with a RC Duo remote to tamper with the sensor.
- There are two ways to regain access for the remote controlled set-up:
  - Power OFF, wait for 5 seconds and power up the sensor.
  - Open the sensor and press the two push buttons simultaneously until the LED begins to flash.

Function Name	Function Key	Description	Output R1	Output R2	
Convenience Functions	C +	1	Standard application	backwards	forward
		2	Frontal traffic	backwards	forward
		3	High speed door	backwards	forward
		4	Detects slow movements	backwards	forward
		5*	Standard application* Factory setting	person	vehicle
		6	Frontal traffic	person	vehicle
		7	High speed industrial door	-	vehicle
		8	Detect slow movements	person	vehicle
Addressing of Sensor	F+8+	--	Address 1*- 4 have to be set with DIP Switch not possible to change with remote!		
		5-7	Sets address 5 - 7		
		9	Reads in address from DIP Switch		
Mounting Height	F+4+	1	6.5 – 7.9 ft	2.0 – 2.4 m	
		2	8.0 – 9.5 ft	2.5 – 2.9 m	
		3	9.6 – 12.8 ft	3.0 – 3.9 m	
		4*	12.9 – 16.0 ft	4.0 – 4.9 m	
		5	16.1 – 19.4 ft	5.0 – 5.9 m	
		6	19.5 – 22.9 ft	6.0 – 6.9 m	
		7	23.0 ft	7.0 m	
Field Size	D +	1-9 (6*)	1 = Smallest field, 9=Largest field		
Direction Recognition	E+1+	1* = Forward towards sensor	2 = Backward away from sensor	3 = Both ways	
Relay Parameterization	E+2+	1*	Standard industrial doors	Differentiation people and vehicles	
		2	Standard industrial doors	People suppression	
		3	Standard industrial doors	Vehicle suppression	
		4	Standard industrial doors	People and Vehicles – same output	
		5*	Standard industrial doors	P/V outputs w/direction recognition	
		6	High Speed industrial doors	People suppression	
		7	High Speed industrial doors	P/V same outputs	
		8	High Speed industrial doors	P/V with direction separation	
Cross traffic optimizing	F+5+	1-9 (1*)	1* = OFF 2 = Low, 9 = High		
Wide field	B +	1 = On (use the clip for extra wide field)		2* = Off	
Slow Motion Detection (SMD)		see user's guide			
Reset to Factory settings	A+	9	Resets all to factory settings		

\*factory settings

## Contact

For any issues, please call Bircher Reglomat at 800.252.1272. You may also visit our website at [www.bircherreglomat.com](http://www.bircherreglomat.com)

## Disclaimer

Bircher Reglomat reserves the right to change any information on this document without notice. Please contact us to make sure you have the latest version.